


RTG-Infinity Demo Unit Quick Start Guide

System Interconnect

There are 3 cables attached to the demo unit:

- A power cable
- An “RTGOM” USB Cable (for the detector side)
- An “RTGLS” USB Cable (for the light source side)

1. Plug the power cable into an AC outlet.
Note: the cable may include a keyed connector that connects to a power adapter found in the box.



2. Connect both of the USB Cables to a Windows 7/8/10 PC or tablet, either directly or through a USB Hub. The connection will cause (a) the LED lights to perform a startup sequence, and (b) the computer to sound the USB-attach tone (if sound is enabled).

Software Load

3. Visit <http://landminstruments.com/infinity-downloads/> to download “L and M Infinity Suite #- #-#”. The download page includes a Readme file with software usage information. This Readme file is also available for launch at the completion of the software installation.
4. Launch the installer that was downloaded above and follow the prompts. This will load the Infinity Software Suite, placing the “L&M Infinity” folder on the desktop.

Run Software. Ready To Go!

5. Find and open the “L&M Infinity” desktop folder and run the “RTGOM_Infinity” application. There are other applications in this folder, all of which are described in the Readme referenced above.

